

Реле безопасности MSI

Технические характеристики

По вопросам продаж и поддержки обращайтесь:

Алматы (727)345-47-04
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Саранск (8342)22-96-24
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +(727)345-47-04

Беларусь +(375)257-127-884

Узбекистан +998(71)205-18-59

Киргизия +996(312)96-26-47

эл.почта: ezu@nt-rt.ru || сайт: <https://leuze.nt-rt.ru/>



MSI-SR4B-01

Safety relay

Application: E-Stop circuits, Optoelectronic protective devices...

Restart: Automatic, Manual

Type of terminal: Screw terminal **Functions:** Cross circuit monitoring, Contactor monitoring (ED...



MSI-SR4B-02

Safety relay

Application: E-Stop circuits, Optoelectronic protective devices...

Restart: Automatic, Manual

Type of terminal: Spring-cage terminal **Functions:** Cross circuit monitoring, Contactor monitoring (ED...



MSI-SR-LC31AR-01

Safety relay

Application: E-Stop circuits, Optoelectronic protective devices...

Restart: Automatic

Type of terminal: Screw terminal **Functions:** Cross circuit monitoring, One- or two-channel actu...



MSI-SR-LC31AR-03

Safety relay

Application: E-Stop circuits, Optoelectronic protective devices...

Restart: Automatic

Type of terminal: Spring-cage terminal **Functions:** Cross circuit monitoring



MSI-SR-LC31MR-01

Safety relay

Application: E-Stop circuits, Optoelectronic protective devices...

Restart: Manual

Type of terminal: Screw terminal **Functions:** Cross circuit monitoring



MSI-SR-LC31MR-03

Safety relay

Application: E-Stop circuits, Optoelectronic protective devices...
Restart: Manual
Type of terminal: Spring-cage terminal **Functions:** Cross circuit monitoring



MSI-SR-LC21-01

Safety relay

Application: E-Stop circuits, Optoelectronic protective devices...
Restart: Automatic, Manual
Type of terminal: Screw terminal **Functions:** Start/restart interlock (RES), Contactor monitorin...



MSI-SR-LC21-03

Safety relay

Application: E-Stop circuits, Optoelectronic protective devices...
Restart: Automatic, Manual
Type of terminal: Spring-cage terminal **Functions:** Start/restart interlock (RES), Contactor monitorin...



MSI-TRMB-01

Safety relay

Application: Evaluation unit for type 4 single beam safety devi...
Restart: Automatic, Manual
Type of terminal: Screw terminal **Functions:** Start/restart interlock (RES), Contactor monitorin...



MSI-TRMB-02

Safety relay

Application: Evaluation unit for type 4 single beam safety devi...
Restart: Automatic, Manual
Type of terminal: Spring-cage terminal



MSI-TR1B-01

Safety relay

Application: Evaluation unit for type 2 single beam safety devi...

Restart: Automatic, Manual

Type of terminal: Screw terminal **Functions:** Periodic function test, "Error" signal output, "Sa...



MSI-TR1B-02

Safety relay

Application: Evaluation unit for type 2 single beam safety devi...

Restart: Automatic, Manual

Type of terminal: Spring-cage terminal **Functions:** Periodic function test, "Error" signal output, "Sa...



MSI-TR2B-01

Safety relay

Application: Evaluation unit for type 2 single beam safety devi...

Restart: Automatic, Manual

Type of terminal: Screw terminal **Functions:** Periodic function test, "Error" signal output, "Sa...



MSI-TR2B-02

Safety relay

Application: Evaluation unit for type 2 single beam safety devi...

Restart: Automatic, Manual

Type of terminal: Spring-cage terminal **Functions:** Periodic function test, "Error" signal output, "Sa...



MSI-SR-2H21-01

Safety relay

Application: Evaluation unit for two-hand control devices in ac...

Restart: Through synchronous actuation **Type of terminal:** Screw

terminal **Functions:** Two-channel actuation (one normally open contact a...



MSI-SR-2H21-03

Safety relay

Application: Evaluation unit for two-hand control devices in ac...

Restart: Through synchronous actuation **Type of terminal:** Spring-cage terminal **Functions:** Two-channel actuation (one normally open contact a...



MSI-SR-LC21DT30-01

Safety relay

Application: Moving guards, electro-sensitive protective equipm...

Restart: Automatic, Manual

Type of terminal: Screw terminal **Functions:** Start/restart interlock (RES), Cross circuit monit...



MSI-SR-LC21DT30-03

Safety relay

Application: Moving guards, electro-sensitive protective equipm...

Restart: Automatic, Manual

Type of terminal: Spring-cage terminal **Functions:** Start/restart interlock (RES), Cross circuit monit...



MSI-SR-ES31-01

Safety relay

Application: E-Stop circuits, Position switches (mechanical con...

Restart: Automatic, Manual

Type of terminal: Screw terminal **Functions:** Start/restart interlock (RES), Contactor monitorin...



MSI-SR-ES31-03

Safety relay

Application: E-Stop circuits, Position switches (mechanical con...

Restart: Automatic, Manual

Type of terminal: Spring-cage terminal
Functions: Start/restart interlock (RES),
Contactor monitorin...



MSI-DT30B-01

Safety relay

Application: Moving guards, electro-sensitive protective equipm...
Restart: Automatic, Manual
Type of terminal: Screw terminal
Functions: Cross circuit monitoring, One- or two-channel oper...



MSI-DT30B-02

Safety relay

Application: Moving guards, electro-sensitive protective equipm...
Restart: Automatic, Manual
Type of terminal: Spring-cage terminal
Functions: Cross circuit monitoring, One- or two-channel oper...



MSI-SR5B-01

Safety relay

Application: E-Stop circuits, Optoelectronic protective devices...
Restart: Automatic, Manual
Type of terminal: Screw terminal
Functions: Double sensor monitoring, Contactor monitoring (ED...



MSI-SR5B-02

Safety relay

Application: E-Stop circuits, Optoelectronic protective devices...
Restart: Automatic, Manual
Type of terminal: Spring-cage terminal
Functions: Double sensor monitoring, Contactor monitoring (ED...



MSI-RM2B-01

Safety relay

Application: Signal conversion of electronic safety outputs on ...

Type of terminal: Screw terminal **Functions:** Feedback path for EDM integration

Contacts: 2 NO contacts / 1 NC contact



MSI-RM2B-02

Safety relay

Application: Signal conversion of electronic safety outputs on ...

Type of terminal: Spring-cage terminal **Functions:** Feedback path for EDM integration

Contacts: 2 NO contacts / 1 NC contact



MSI-SR-CM42R-01

Safety relay

Application: Extension unit for base devices in safety applicat...

Type of terminal: Screw terminal

Contacts: 2 x (2 NO contacts / 1 NC contact)



MSI-SR-CM42R-03

Safety relay

Application: Extension unit for base devices in safety applicat...

Type of terminal: Spring-cage terminal **Contacts:** 2 x (2 NO contacts / 1 NC contact)



MSI-SR-CM43-01

Safety relay

Application: Extension unit for safety relays **Type of terminal:** Screw

terminal **Functions:** Monitoring of proximity switches **Contacts:** 4 NO contacts / 3 NC contacts



MSI-SR-CM43-03

Safety relay

Application: Extension unit for safety relays **Type of terminal:** Spring-cage terminal **Functions:** Monitoring of proximity switches **Contacts:** 4 NO contacts / 3 NC contacts



MSI-MC310

Safety relay

Application: Evaluation unit for magnetically coded sensors wit...
Restart: Automatic, Manual
Type of terminal: Screw terminal **Functions:** Start/restart interlock (RES), For stop category 0...

По вопросам продаж и поддержки обращайтесь:

Алматы (727)345-47-04
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Саранск (8342)22-96-24
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +(727)345-47-04

Беларусь +(375)257-127-884

Узбекистан +998(71)205-18-59

Киргизия +996(312)96-26-47

эл.почта: ezu@nt-rt.ru || сайт: <https://leuze.nt-rt.ru/>