

Компактные считыватели 1D штрих-кодов

Технические характеристики

По вопросам продаж и поддержки обращайтесь:

Алматы (727)345-47-04
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Саранск (8342)22-96-24
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +(727)345-47-04

Беларусь +(375)257-127-884

Узбекистан +998(71)205-18-59

Киргизия +996(312)96-26-47

эл.почта: ezu@nt-rt.ru || сайт: <https://leuze.nt-rt.ru/>



BCL 258i R1M 110

Stationary bar code reader

Series: BCL 200i

Interface: EtherNet IP

Functions: AutoReflAct, Alignment mode, AutoConfig, AutoContr...



BCL 258i SM 110

Stationary bar code reader

Series: BCL 200i

Interface: EtherNet IP

Functions: AutoReflAct, Alignment mode, AutoConfig, AutoContr...



BCL 248i R1M 110

Stationary bar code reader

Series: BCL 200i

Interface: PROFINET

Functions: Reference code comparison, Alignment mode, AutoCon...



BCL 248i SM 110

Stationary bar code reader

Series: BCL 200i

Interface: PROFINET

Functions: AutoControl, Alignment mode, AutoConfig, AutoReflA...



BCL 208i R1M 110

Stationary bar code

Series: BCL 200i

Interface: Ethernet

Functions: Code fragment technology, Alignment mode, AutoConf...



BCL 208i SM 110

Stationary bar code reader

Series: BCL 200i

Interface: Ethernet

Functions: AutoReflAct, Alignment mode, AutoConfig, AutoContr...



BCL 338i R1 M 100 D H F007

Stationary bar code reader

Series: BCL 300i

Interface: EtherCAT

Functions: AutoReflAct, Alignment mode, AutoConfig, AutoContr...



BCL 338i O L 100 D H F007

Stationary bar code reader

Series: BCL 300i

Interface: EtherCAT

Functions: Code fragment technology, Alignment mode, AutoConf...



BCL 338i O F 100 D H F007

Stationary bar code

Series: BCL 300i

Interface: EtherCAT

Functions: Code fragment technology, Alignment mode, AutoConf...



BCL 338i O M 100 D H F007

Stationary bar code reader

Series: BCL 300i

Interface: EtherCAT

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 338i O L 100 D F007

Stationary bar code reader

Series: BCL 300i

Interface: EtherCAT

Functions: Alignment mode, AutoConfig, AutoControl, AutoReflA...



BCL 338i O F 100 D F007

Stationary bar code reader

Series: BCL 300i

Interface: EtherCAT

Functions: AutoControl, Alignment mode, AutoConfig, AutoReflA...



BCL 338i O M 100 D F007

Stationary bar code reader

Series: BCL 300i

Interface: EtherCAT

Functions: AutoRefIAct, Alignment mode, AutoConfig, AutoContr...



BCL 338i O L 100 F007

Stationary bar code reader

Series: BCL 300i

Interface: EtherCAT

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 338i O F 100 F007

Stationary bar code reader

Series: BCL 300i

Interface: EtherCAT

Functions: AutoControl, Alignment mode, AutoConfig, AutoReflA...



BCL 338i O M 100 F007

Stationary bar code reader

Series: BCL 300i

Interface: EtherCAT

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 338i R1 F 100 D F007

Stationary bar code

Series: BCL 300i

Interface: EtherCAT

Functions: Reference code comparison, Alignment mode, AutoCon...



BCL 338i R1 M 100 D F007

Stationary bar code reader

Series: BCL 300i

Interface: EtherCAT

Functions: Code fragment technology, Alignment mode, AutoConf...



BCL 338i R1 N 100 D F007

Stationary bar code reader

Series: BCL 300i

Interface: EtherCAT

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 338i R1 J 100 F007

Stationary bar code reader

Series: BCL 300i

Interface: EtherCAT

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 338i R1 F 100 F007

Stationary bar code

Series: BCL 300i

Interface: EtherCAT

Functions: Alignment mode, AutoConfig, AutoControl, AutoRefIA...



BCL 338i R1 M 100 F007

Stationary bar code reader

Series: BCL 300i

Interface: EtherCAT

Functions: AutoControl, Alignment mode, AutoConfig, AutoRefIA...



BCL 338i R1 N 100 F007

Stationary bar code reader

Series: BCL 300i

Interface: EtherCAT

Functions: LED indicator, Alignment mode, AutoConfig, AutoCon...



BCL 338i S L 100 D H F007

Stationary bar code reader

Series: BCL 300i

Interface: EtherCAT

Functions: LED indicator, Alignment mode, AutoConfig, AutoCon...



BCL 338i S F 100 D H F007

Stationary bar code reader

Series: BCL 300i

Interface: EtherCAT

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 338i S M 100 D H F007

Stationary bar code reader

Series: BCL 300i

Interface: EtherCAT

Functions: Heating, Alignment mode, AutoConfig, AutoControl, ...



BCL 338i S N 100 D H F007

Stationary bar code reader

Series: BCL 300i

Interface: EtherCAT

Functions: Alignment mode, AutoConfig, AutoControl, AutoReflA...



BCL 338i S L 100 D F007

Stationary bar code reader

Series: BCL 300i

Interface: EtherCAT

Functions: AutoReflAct, Alignment mode, AutoConfig, AutoContr...



BCL 338i S F 100 D F007

Stationary bar code

Series: BCL 300i

Interface: EtherCAT

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 338i S M 100 D F007

Stationary bar code reader

Series: BCL 300i

Interface: EtherCAT

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 338i S N 100 D F007

Stationary bar code reader

Series: BCL 300i

Interface: EtherCAT

Functions: Code fragment technology, Alignment mode, AutoConf...



BCL 338i S L 100 F007

Stationary bar code reader

Series: BCL 300i

Interface: EtherCAT

Functions: Code fragment technology, Alignment mode, AutoConf...



BCL 338i S F 100 F007

Stationary bar code

Series: BCL 300i

Interface: EtherCAT

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 338i S M 100 F007

Stationary bar code reader

Series: BCL 300i

Interface: EtherCAT

Functions: AutoReflAct, Alignment mode, AutoConfig, AutoContr...



BCL 338i S N 100 F007

Stationary bar code reader

Series: BCL 300i

Interface: EtherCAT

Functions: AutoReflAct, Alignment mode, AutoConfig, AutoContr...



BCL 338i R1 F 102 D F007

Stationary bar code reader

Series: BCL 300i

Interface: EtherCAT

Functions: Code fragment technology, Alignment mode, AutoConf...



BCL 338i R1 M 102 D F007

Stationary bar code reader

Series: BCL 300i

Interface: EtherCAT

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 338i R1 N 102 D F007

Stationary bar code reader

Series: BCL 300i

Interface: EtherCAT

Functions: Alignment mode, AutoConfig, AutoControl, AutoReflA...



BCL 338i R1 F 102 F007

Stationary bar code reader

Series: BCL 300i

Interface: EtherCAT

Functions: AutoReflAct, Alignment mode, AutoConfig, AutoContr...



BCL 338i R1 M 102 F007

Stationary bar code reader

Series: BCL 300i

Interface: EtherCAT

Functions: LED indicator, Alignment mode, AutoConfig, AutoCon...



BCL 338i R1 N 102 F007

Stationary bar code

Series: BCL 300i

Interface: EtherCAT

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 338i SL 102 D H F007

Stationary bar code reader

Series: BCL 300i

Interface: EtherCAT

Functions: AutoReflAct, Alignment mode, AutoConfig, AutoContr...



BCL 338i SF 102 D H F007

Stationary bar code reader

Series: BCL 300i

Interface: EtherCAT

Functions: Reference code comparison, Alignment mode, AutoCon...



BCL 338i SM 102 D H F007

Stationary bar code reader

Series: BCL 300i

Interface: EtherCAT

Functions: AutoControl, Alignment mode, AutoConfig, AutoReflA...



BCL 338i SN 102 D H F007

Stationary bar code

Series: BCL 300i

Interface: EtherCAT

Functions: Reference code comparison, Alignment mode, AutoCon...



BCL 338i SL 102 D F007

Stationary bar code reader

Series: BCL 300i

Interface: EtherCAT

Functions: LED indicator, Alignment mode, AutoConfig, AutoCon...



BCL 338i SF 102 D F007

Stationary bar code reader

Series: BCL 300i

Interface: EtherCAT

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 338i SM 102 D F007

Stationary bar code reader

Series: BCL 300i

Interface: EtherCAT

Functions: LED indicator, Alignment mode, AutoConfig, AutoCon...



BCL 338i SN 102 D F007

Stationary bar code reader

Series: BCL 300i

Interface: EtherCAT

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 338i SL 102 F007

Stationary bar code reader

Series: BCL 300i

Interface: EtherCAT

Functions: Alignment mode, AutoConfig, AutoControl, AutoReflA...



BCL 338i SF 102 F007

Stationary bar code reader

Series: BCL 300i

Interface: EtherCAT

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 338i SM 102 F007

Stationary bar code reader

Series: BCL 300i

Interface: EtherCAT

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 338i SN 102 F007

Stationary bar code

Series: BCL 300i

Interface: EtherCAT

Functions: Code fragment technology, Alignment mode, AutoConf...



BCL 308iC SF 102 D F 099

Stationary bar code reader

Series: BCL 300i

Interface: Ethernet, OPC-UA

Functions: Code fragment technology, Alignment mode, AutoConf...



BCL 358i SM 102 P

Stationary bar code reader

Series: BCL 300i

Interface: EtherNet IP

Functions: LED indicator, Alignment mode, AutoConfig, AutoCon...



BCL 308i R1 M 102 P

Stationary bar code reader

Series: BCL 300i

Interface: Ethernet

Functions: AutoReflAct, Alignment mode, AutoConfig, AutoContr...



BCL 358i R1 J 100 D H

Stationary bar code

Series: BCL 300i

Interface: EtherNet IP

Functions: AutoControl, Alignment mode, AutoConfig, AutoReflA...



BCL 308i R1 J 100 D H

Stationary bar code reader

Series: BCL 300i

Interface: Ethernet

Functions: Code fragment technology, Alignment mode, AutoConf...



BCL 304i R1 J 100 D H

Stationary bar code reader

Series: BCL 300i

Interface: PROFIBUS DP

Functions: Alignment mode, AutoConfig, AutoControl, AutoReflA...



BCL 301i R1 J 100 D H

Stationary bar code reader

Series: BCL 300i

Interface: MultiNet Plus, RS 485

Functions: AutoControl, Alignment mode, AutoConfig, AutoReflA...



BCL 300i R1 J 100 D H

Stationary bar code reader

Series: BCL 300i

Interface: RS 422, RS 232

Functions: Alignment mode, AutoConfig, AutoControl, AutoRefIA...



BCL 348i R1 J 100 D H

Stationary bar code reader

Series: BCL 300i

Interface: PROFINET

Functions: AutoControl, Alignment mode, AutoConfig, AutoRefIA...



BCL 300i R1 J 100

Stationary bar code reader

Series: BCL 300i

Interface: RS 422, RS 232

Functions: Code fragment technology, Alignment mode, AutoConf...



BCL 301i R1 J 100

Stationary bar code reader

Series: BCL 300i

Interface: MultiNet Plus, RS 485

Functions: Code fragment technology, Alignment mode, AutoConf...



BCL 304i R1 J 100

Stationary bar code

Series: BCL 300i

Interface: PROFIBUS DP

Functions: Code fragment technology,
Alignment mode, AutoConf...



BCL 308i R1 J 100

Stationary bar code reader

Series: BCL 300i

Interface: Ethernet

Functions: Code fragment technology,
Alignment mode, AutoConf...



BCL 348i R1 J 100

Stationary bar code reader

Series: BCL 300i

Interface: PROFINET

Functions: Code fragment technology,
Alignment mode, AutoConf...



BCL 358i R1 J 100

Stationary bar code reader

Series: BCL 300i

Interface: EtherNet IP

Functions: Code fragment technology,
Alignment mode, AutoConf...



BCL 358i SN 102 D H

Stationary bar code

Series: BCL 300i

Interface: EtherNet IP

Functions: Code fragment technology, Alignment mode, AutoConf...



BCL 358i SN 102 D

Stationary bar code reader

Series: BCL 300i

Interface: EtherNet IP

Functions: Code fragment technology, Alignment mode, AutoConf...



BCL 358i SN 102

Stationary bar code reader

Series: BCL 300i

Interface: EtherNet IP

Functions: Code fragment technology, Alignment mode, AutoConf...



BCL 358i SN 100 D H

Stationary bar code reader

Series: BCL 300i

Interface: EtherNet IP

Functions: Code fragment technology, Alignment mode, AutoConf...



BCL 358i SN 100 D

Stationary bar code reader

Series: BCL 300i

Interface: EtherNet IP

Functions: Code fragment technology, Alignment mode, AutoConf...



BCL 358i SN 100

Stationary bar code reader

Series: BCL 300i

Interface: EtherNet IP

Functions: Code fragment technology, Alignment mode, AutoConf...



BCL 358i SM 102 D H

Stationary bar code reader

Series: BCL 300i

Interface: EtherNet IP

Functions: Code fragment technology, Alignment mode, AutoConf...



BCL 358i SM 102 D

Stationary bar code reader

Series: BCL 300i

Interface: EtherNet IP

Functions: Code fragment technology, Alignment mode, AutoConf...



BCL 358i SM 102

Stationary bar code

Series: BCL 300i

Interface: EtherNet IP

Functions: Code fragment technology, Alignment mode, AutoConf...



BCL 358i SM 100 D H

Stationary bar code reader

Series: BCL 300i

Interface: EtherNet IP

Functions: Code fragment technology, Alignment mode, AutoConf...



BCL 358i SM 100 D

Stationary bar code reader

Series: BCL 300i

Interface: EtherNet IP

Functions: Code fragment technology, Alignment mode, AutoConf...



BCL 358i SM 100

Stationary bar code reader

Series: BCL 300i

Interface: EtherNet IP

Functions: Code fragment technology, Alignment mode, AutoConf...



BCL 358i SL 102 D H

Stationary bar code

Series: BCL 300i

Interface: EtherNet IP

Functions: Code fragment technology, Alignment mode, AutoConf...



BCL 358i SL 102 D

Stationary bar code reader

Series: BCL 300i

Interface: EtherNet IP

Functions: Code fragment technology, Alignment mode, AutoConf...



BCL 358i SL 102

Stationary bar code reader

Series: BCL 300i

Interface: EtherNet IP

Functions: Code fragment technology, Alignment mode, AutoConf...



BCL 358i SL 100 D H

Stationary bar code reader

Series: BCL 300i

Interface: EtherNet IP

Functions: Code fragment technology, Alignment mode, AutoConf...



BCL 358i SL 100 D

Stationary bar code reader

Series: BCL 300i

Interface: EtherNet IP

Functions: Code fragment technology, Alignment mode, AutoConf...



BCL 358i SL 100

Stationary bar code reader

Series: BCL 300i

Interface: EtherNet IP

Functions: Code fragment technology, Alignment mode, AutoConf...



BCL 358i SF 102 D H

Stationary bar code reader

Series: BCL 300i

Interface: EtherNet IP

Functions: Code fragment technology, Alignment mode, AutoConf...



BCL 358i SF 102 D

Stationary bar code reader

Series: BCL 300i

Interface: EtherNet IP

Functions: Code fragment technology, Alignment mode, AutoConf...



BCL 358i SF 102

Stationary bar code

Series: BCL 300i

Interface: EtherNet IP

Functions: Code fragment technology, Alignment mode, AutoConf...



BCL 358i SF 100 D H

Stationary bar code reader

Series: BCL 300i

Interface: EtherNet IP

Functions: Code fragment technology, Alignment mode, AutoConf...



BCL 358i SF 100 D

Stationary bar code reader

Series: BCL 300i

Interface: EtherNet IP

Functions: Code fragment technology, Alignment mode, AutoConf...



BCL 358i SF 100

Stationary bar code reader

Series: BCL 300i

Interface: EtherNet IP

Functions: Code fragment technology, Alignment mode, AutoConf...



BCL 358i R1 N 102 D

Stationary bar code

Series: BCL 300i

Interface: EtherNet IP

Functions: Code fragment technology, Alignment mode, AutoConf...



BCL 358i R1 N 102

Stationary bar code reader

Series: BCL 300i

Interface: EtherNet IP

Functions: Code fragment technology, Alignment mode, AutoConf...



BCL 358i R1 N 100 D

Stationary bar code reader

Series: BCL 300i

Interface: EtherNet IP

Functions: Code fragment technology, Alignment mode, AutoConf...



BCL 358i R1 N 100

Stationary bar code reader

Series: BCL 300i

Interface: EtherNet IP

Functions: Code fragment technology, Alignment mode, AutoConf...



BCL 358i R1 M 102 D

Stationary bar code reader

Series: BCL 300i

Interface: EtherNet IP

Functions: Code fragment technology, Alignment mode, AutoConf...



BCL 358i R1 M 102

Stationary bar code reader

Series: BCL 300i

Interface: EtherNet IP

Functions: Code fragment technology, Alignment mode, AutoConf...



BCL 358i R1 M 100 D

Stationary bar code reader

Series: BCL 300i

Interface: EtherNet IP

Functions: Code fragment technology, Alignment mode, AutoConf...



BCL 358i R1 M 100

Stationary bar code reader

Series: BCL 300i

Interface: EtherNet IP

Functions: Code fragment technology, Alignment mode, AutoConf...



BCL 358i R1 F 102 D

Stationary bar code

Series: BCL 300i

Interface: EtherNet IP

Functions: Code fragment technology, Alignment mode, AutoConf...



BCL 358i R1 F 102

Stationary bar code reader

Series: BCL 300i

Interface: EtherNet IP

Functions: Code fragment technology, Alignment mode, AutoConf...



BCL 358i R1 F 100 D

Stationary bar code reader

Series: BCL 300i

Interface: EtherNet IP

Functions: Code fragment technology, Alignment mode, AutoConf...



BCL 358i R1 F 100

Stationary bar code reader

Series: BCL 300i

Interface: EtherNet IP

Functions: Code fragment technology, Alignment mode, AutoConf...



BCL 358i OM 100 D H

Stationary bar code

Series: BCL 300i

Interface: EtherNet IP

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 358i OM 100 D

Stationary bar code reader

Series: BCL 300i

Interface: EtherNet IP

Functions: AutoControl, Alignment mode, AutoConfig, AutoReflA...



BCL 358i OM 100

Stationary bar code reader

Series: BCL 300i

Interface: EtherNet IP

Functions: AutoControl, Alignment mode, AutoConfig, AutoReflA...



BCL 358i OL 100 D H

Stationary bar code reader

Series: BCL 300i

Interface: EtherNet IP

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 358i OL 100 D

Stationary bar code reader

Series: BCL 300i

Interface: EtherNet IP

Functions: AutoControl, Alignment mode, AutoConfig, AutoReflA...



BCL 358i OL 100

Stationary bar code reader

Series: BCL 300i

Interface: EtherNet IP

Functions: AutoControl, Alignment mode, AutoConfig, AutoReflA...



BCL 358i OF 100 D H

Stationary bar code reader

Series: BCL 300i

Interface: EtherNet IP

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 358i OF 100 D

Stationary bar code reader

Series: BCL 300i

Interface: EtherNet IP

Functions: AutoControl, Alignment mode, AutoConfig, AutoReflA...



BCL 358i OF 100

Stationary bar code

Series: BCL 300i

Interface: EtherNet IP

Functions: AutoControl, Alignment mode, AutoConfig, AutoReflA...



BCL 348i SN 102

Stationary bar code reader

Series: BCL 300i

Interface: PROFINET

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 348i SN 102 D

Stationary bar code reader

Series: BCL 300i

Interface: PROFINET

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 348i SN 102 D H

Stationary bar code reader

Series: BCL 300i

Interface: PROFINET

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 348i SN 100

Stationary bar code

Series: BCL 300i

Interface: PROFINET

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 348i SN 100 D

Stationary bar code reader

Series: BCL 300i

Interface: PROFINET

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 348i SN 100 D H

Stationary bar code reader

Series: BCL 300i

Interface: PROFINET

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 348i SM 102

Stationary bar code reader

Series: BCL 300i

Interface: PROFINET

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 348i SM 102 D

Stationary bar code reader

Series: BCL 300i

Interface: PROFINET

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 348i SM 102 D H

Stationary bar code reader

Series: BCL 300i

Interface: PROFINET

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 348i SM 100 D

Stationary bar code reader

Series: BCL 300i

Interface: PROFINET

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 348i SM 100 D H

Stationary bar code reader

Series: BCL 300i

Interface: PROFINET

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 348i SM 100

Stationary bar code

Series: BCL 300i

Interface: PROFINET

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 348i SL 102

Stationary bar code reader

Series: BCL 300i

Interface: PROFINET

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 348i SL 102 D

Stationary bar code reader

Series: BCL 300i

Interface: PROFINET

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 348i SL 102 D H

Stationary bar code reader

Series: BCL 300i

Interface: PROFINET

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 348i SL 100

Stationary bar code

Series: BCL 300i

Interface: PROFINET

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 348i S L 100 D

Stationary bar code reader

Series: BCL 300i

Interface: PROFINET

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 348i SL 100 D H

Stationary bar code reader

Series: BCL 300i

Interface: PROFINET

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 348i SF 102

Stationary bar code reader

Series: BCL 300i

Interface: PROFINET

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 348i SF 102 D

Stationary bar code reader

Series: BCL 300i

Interface: PROFINET

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 348i SF 102 D H

Stationary bar code reader

Series: BCL 300i

Interface: PROFINET

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 348i SF 100

Stationary bar code reader

Series: BCL 300i

Interface: PROFINET

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 348i SF 100 D

Stationary bar code reader

Series: BCL 300i

Interface: PROFINET

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 348i SF 100 D H

Stationary bar code

Series: BCL 300i

Interface: PROFINET

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 348i R1 N 102

Stationary bar code reader

Series: BCL 300i

Interface: PROFINET

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 348i R1 N 102 D

Stationary bar code reader

Series: BCL 300i

Interface: PROFINET

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 348i R1 N 100

Stationary bar code reader

Series: BCL 300i

Interface: PROFINET

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 348i R1 N 100 D

Stationary bar code

Series: BCL 300i

Interface: PROFINET

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 348i R1 M 102

Stationary bar code reader

Series: BCL 300i

Interface: PROFINET

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 348i R1 M 102 D

Stationary bar code reader

Series: BCL 300i

Interface: PROFINET

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 348i R1 M 100

Stationary bar code reader

Series: BCL 300i

Interface: PROFINET

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 348i R1 M 100 D

Stationary bar code reader

Series: BCL 300i

Interface: PROFINET

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 348i R1 F 102

Stationary bar code reader

Series: BCL 300i

Interface: PROFINET

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 348i R1 F 102 D

Stationary bar code reader

Series: BCL 300i

Interface: PROFINET

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 348i R1 F 100

Stationary bar code reader

Series: BCL 300i

Interface: PROFINET

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 348i R1 F 100 D

Stationary bar code

Series: BCL 300i

Interface: PROFINET

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 348i OM 100 D H

Stationary bar code reader

Series: BCL 300i

Interface: PROFINET

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 348i OM 100 D

Stationary bar code reader

Series: BCL 300i

Interface: PROFINET

Functions: AutoControl, Alignment mode, AutoConfig, AutoReflA...



BCL 348i OM 100

Stationary bar code reader

Series: BCL 300i

Interface: PROFINET

Functions: AutoControl, Alignment mode, AutoConfig, AutoReflA...



BCL 348i OL 100 D H

Stationary bar code

Series: BCL 300i

Interface: PROFINET

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 348i OL 100 D

Stationary bar code reader

Series: BCL 300i

Interface: PROFINET

Functions: AutoControl, Alignment mode, AutoConfig, AutoReflA...



BCL 348i OL 100

Stationary bar code reader

Series: BCL 300i

Interface: PROFINET

Functions: AutoControl, Alignment mode, AutoConfig, AutoReflA...



BCL 348i OF 100 D H

Stationary bar code reader

Series: BCL 300i

Interface: PROFINET

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 348i OF 100 D

Stationary bar code reader

Series: BCL 300i

Interface: PROFINET

Functions: AutoControl, Alignment mode, AutoConfig, AutoReflA...



BCL 348i OF 100

Stationary bar code reader

Series: BCL 300i

Interface: PROFINET

Functions: AutoControl, Alignment mode, AutoConfig, AutoReflA...



BCL 308i SN 102

Stationary bar code reader

Series: BCL 300i

Interface: Ethernet

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 308i SN 102 D

Stationary bar code reader

Series: BCL 300i

Interface: Ethernet

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 308i SN 102 D H

Stationary bar code

Series: BCL 300i

Interface: Ethernet

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 308i SN 100

Stationary bar code reader

Series: BCL 300i

Interface: Ethernet

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 308i SN 100 D

Stationary bar code reader

Series: BCL 300i

Interface: Ethernet

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 308i SN 100 D H

Stationary bar code reader

Series: BCL 300i

Interface: Ethernet

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 308i SM 102

Stationary bar code

Series: BCL 300i

Interface: Ethernet

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 308i SM 102 D

Stationary bar code reader

Series: BCL 300i

Interface: Ethernet

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 308i SM 102 D H

Stationary bar code reader

Series: BCL 300i

Interface: Ethernet

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 308i SM 100

Stationary bar code reader

Series: BCL 300i

Interface: Ethernet

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 308i SM 100 D

Stationary bar code reader

Series: BCL 300i

Interface: Ethernet

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 308i SM 100 D H

Stationary bar code reader

Series: BCL 300i

Interface: Ethernet

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 308i SL 102

Stationary bar code reader

Series: BCL 300i

Interface: Ethernet

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 308i SL 102 D

Stationary bar code reader

Series: BCL 300i

Interface: Ethernet

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 308i SL 102 D H

Stationary bar code

Series: BCL 300i

Interface: Ethernet

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 308i SL 100

Stationary bar code reader

Series: BCL 300i

Interface: Ethernet

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 308i SL 100 D

Stationary bar code reader

Series: BCL 300i

Interface: Ethernet

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 308i SL 100 D H

Stationary bar code reader

Series: BCL 300i

Interface: Ethernet

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 308i SF 102

Stationary bar code

Series: BCL 300i

Interface: Ethernet

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 308i SF 102 D H

Stationary bar code reader

Series: BCL 300i

Interface: Ethernet

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 308i SF 100

Stationary bar code reader

Series: BCL 300i

Interface: Ethernet

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 308i SF 100 D

Stationary bar code reader

Series: BCL 300i

Interface: Ethernet

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 308i SF 100 D H

Stationary bar code reader

Series: BCL 300i

Interface: Ethernet

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 308i R1 N 102

Stationary bar code reader

Series: BCL 300i

Interface: Ethernet

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 308i R1 N 102 D

Stationary bar code reader

Series: BCL 300i

Interface: Ethernet

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 308i R1 N 100

Stationary bar code reader

Series: BCL 300i

Interface: Ethernet

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 308i R1 N 100 D

Stationary bar code

Series: BCL 300i

Interface: Ethernet

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 308i R1 M 102

Stationary bar code reader

Series: BCL 300i

Interface: Ethernet

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 308i R1 M 102 D

Stationary bar code reader

Series: BCL 300i

Interface: Ethernet

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 308i R1 M 100

Stationary bar code reader

Series: BCL 300i

Interface: Ethernet

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 308i R1 M 100 D

Stationary bar code

Series: BCL 300i

Interface: Ethernet

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 308i R1 F 102

Stationary bar code reader

Series: BCL 300i

Interface: Ethernet

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 308i R1 F 102 D

Stationary bar code reader

Series: BCL 300i

Interface: Ethernet

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 308i R1 F 100

Stationary bar code reader

Series: BCL 300i

Interface: Ethernet

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 308i R1 F 100 D

Stationary bar code reader

Series: BCL 300i

Interface: Ethernet

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 308i OM 100 D H

Stationary bar code reader

Series: BCL 300i

Interface: Ethernet

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 308i OM 100 D

Stationary bar code reader

Series: BCL 300i

Interface: Ethernet

Functions: AutoControl, Alignment mode, AutoConfig, AutoReflA...



BCL 308i OM 100

Stationary bar code reader

Series: BCL 300i

Interface: Ethernet

Functions: AutoControl, Alignment mode, AutoConfig, AutoReflA...



BCL 308i OL 100 D H

Stationary bar code

Series: BCL 300i

Interface: Ethernet

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 308i OL 100 D

Stationary bar code reader

Series: BCL 300i

Interface: Ethernet

Functions: AutoControl, Alignment mode, AutoConfig, AutoReflA...



BCL 308i OL 100

Stationary bar code reader

Series: BCL 300i

Interface: Ethernet

Functions: AutoControl, Alignment mode, AutoConfig, AutoReflA...



BCL 308i OF 100 D H

Stationary bar code reader

Series: BCL 300i

Interface: Ethernet

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 308i OF 100 D

Stationary bar code

Series: BCL 300i

Interface: Ethernet

Functions: AutoControl, Alignment mode, AutoConfig, AutoReflA...



BCL 308i OF 100

Stationary bar code reader

Series: BCL 300i

Interface: Ethernet

Functions: AutoControl, Alignment mode, AutoConfig, AutoReflA...



BCL 304i SN 102

Stationary bar code reader

Series: BCL 300i

Interface: PROFIBUS DP

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 304i SN 102 D

Stationary bar code reader

Series: BCL 300i

Interface: PROFIBUS DP

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 304i SN 102 D H

Stationary bar code reader

Series: BCL 300i

Interface: PROFIBUS DP

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 304i SN 100

Stationary bar code reader

Series: BCL 300i

Interface: PROFIBUS DP

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 304i SN 100 D

Stationary bar code reader

Series: BCL 300i

Interface: PROFIBUS DP

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 304i SN 100 D H

Stationary bar code reader

Series: BCL 300i

Interface: PROFIBUS DP

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 304i SM 102

Stationary bar code

Series: BCL 300i

Interface: PROFIBUS DP

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 304i SM 102 D

Stationary bar code reader

Series: BCL 300i

Interface: PROFIBUS DP

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 304i SM 102 D H

Stationary bar code reader

Series: BCL 300i

Interface: PROFIBUS DP

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 304i SM 100

Stationary bar code reader

Series: BCL 300i

Interface: PROFIBUS DP

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 304i SM 100 D

Stationary bar code

Series: BCL 300i

Interface: PROFIBUS DP

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 304i SM 100 D H

Stationary bar code reader

Series: BCL 300i

Interface: PROFIBUS DP

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 304i SL 102

Stationary bar code reader

Series: BCL 300i

Interface: PROFIBUS DP

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 304i SL 102 D

Stationary bar code reader

Series: BCL 300i

Interface: PROFIBUS DP

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 304i SL 102 D H

Stationary bar code reader

Series: BCL 300i

Interface: PROFIBUS DP

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 304i SL 100

Stationary bar code reader

Series: BCL 300i

Interface: PROFIBUS DP

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 304i SL 100 D

Stationary bar code reader

Series: BCL 300i

Interface: PROFIBUS DP

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 304i SL 100 D H

Stationary bar code reader

Series: BCL 300i

Interface: PROFIBUS DP

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 304i SF 102

Stationary bar code

Series: BCL 300i

Interface: PROFIBUS DP

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 304i SF 102 D

Stationary bar code reader

Series: BCL 300i

Interface: PROFIBUS DP

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 304i SF 102 D H

Stationary bar code reader

Series: BCL 300i

Interface: PROFIBUS DP

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 304i SF 100

Stationary bar code reader

Series: BCL 300i

Interface: PROFIBUS DP

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 304i SF 100 D

Stationary bar code

Series: BCL 300i

Interface: PROFIBUS DP

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 304i SF 100 D H

Stationary bar code reader

Series: BCL 300i

Interface: PROFIBUS DP

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 304i R1 N 102

Stationary bar code reader

Series: BCL 300i

Interface: PROFIBUS DP

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 304i R1 N 102 D

Stationary bar code reader

Series: BCL 300i

Interface: PROFIBUS DP

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 304i R1 N 100

Stationary bar code reader

Series: BCL 300i

Interface: PROFIBUS DP

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 304i R1 N 100 D

Stationary bar code reader

Series: BCL 300i

Interface: PROFIBUS DP

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 304i R1 M 102

Stationary bar code reader

Series: BCL 300i

Interface: PROFIBUS DP

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 304i R1 M 102 D

Stationary bar code reader

Series: BCL 300i

Interface: PROFIBUS DP

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 304i R1 M 100

Stationary bar code

Series: BCL 300i

Interface: PROFIBUS DP

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 304i R1 M 100 D

Stationary bar code reader

Series: BCL 300i

Interface: PROFIBUS DP

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 304i R1 F 102

Stationary bar code reader

Series: BCL 300i

Interface: PROFIBUS DP

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 304i R1 F 102 D

Stationary bar code reader

Series: BCL 300i

Interface: PROFIBUS DP

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 304i R1 F 100

Stationary bar code

Series: BCL 300i

Interface: PROFIBUS DP

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 304i R1 F 100 D

Stationary bar code reader

Series: BCL 300i

Interface: PROFIBUS DP

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 304i OM 100 D H

Stationary bar code reader

Series: BCL 300i

Interface: PROFIBUS DP

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 304i OM 100 D

Stationary bar code reader

Series: BCL 300i

Interface: PROFIBUS DP

Functions: AutoControl, Alignment mode, AutoConfig, AutoReflA...



BCL 304i OM 100

Stationary bar code reader

Series: BCL 300i

Interface: PROFIBUS DP

Functions: AutoControl, Alignment mode, AutoConfig, AutoReflA...



BCL 304i OL 100 D H

Stationary bar code reader

Series: BCL 300i

Interface: PROFIBUS DP

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 304i OL 100 D

Stationary bar code reader

Series: BCL 300i

Interface: PROFIBUS DP

Functions: AutoControl, Alignment mode, AutoConfig, AutoReflA...



BCL 304i OL 100

Stationary bar code reader

Series: BCL 300i

Interface: PROFIBUS DP

Functions: AutoControl, Alignment mode, AutoConfig, AutoReflA...



BCL 304i OF 100 D H

Stationary bar code

Series: BCL 300i

Interface: PROFIBUS DP

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 304i OF 100 D

Stationary bar code reader

Series: BCL 300i

Interface: PROFIBUS DP

Functions: AutoControl, Alignment mode, AutoConfig, AutoReflA...



BCL 304i OF 100

Stationary bar code reader

Series: BCL 300i

Interface: PROFIBUS DP

Functions: AutoControl, Alignment mode, AutoConfig, AutoReflA...



BCL 301i SN 102

Stationary bar code reader

Series: BCL 300i

Interface: MultiNet Plus, RS 485

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 301i SN 102 D

Stationary bar code

Series: BCL 300i

Interface: MultiNet Plus, RS 485

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 301i SN 102 D H

Stationary bar code reader

Series: BCL 300i

Interface: MultiNet Plus, RS 485

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 301i SN 100

Stationary bar code reader

Series: BCL 300i

Interface: MultiNet Plus, RS 485

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 301i SN 100 D

Stationary bar code reader

Series: BCL 300i

Interface: MultiNet Plus, RS 485

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 301i SN 100 D H

Stationary bar code reader

Series: BCL 300i

Interface: MultiNet Plus, RS 485

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 301i SM 102

Stationary bar code reader

Series: BCL 300i

Interface: MultiNet Plus, RS 485

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 301i SM 102 D

Stationary bar code reader

Series: BCL 300i

Interface: MultiNet Plus, RS 485

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 301i SM 102 D H

Stationary bar code reader

Series: BCL 300i

Interface: MultiNet Plus, RS 485

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 301i SM 100 D

Stationary bar code

Series: BCL 300i

Interface: MultiNet Plus, RS 485

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 301i SM 100 D H

Stationary bar code reader

Series: BCL 300i

Interface: MultiNet Plus, RS 485

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 301i SM 100

Stationary bar code reader

Series: BCL 300i

Interface: MultiNet Plus, RS 485

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 301i SL 102

Stationary bar code reader

Series: BCL 300i

Interface: MultiNet Plus, RS 485

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 301i SL 102 D

Stationary bar code

Series: BCL 300i

Interface: MultiNet Plus, RS 485

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 301i SL 102 D H

Stationary bar code reader

Series: BCL 300i

Interface: MultiNet Plus, RS 485

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 301i SL 100

Stationary bar code reader

Series: BCL 300i

Interface: MultiNet Plus, RS 485

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 301i SL 100 D

Stationary bar code reader

Series: BCL 300i

Interface: MultiNet Plus, RS 485

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 301i SL 100 D H

Stationary bar code reader

Series: BCL 300i

Interface: MultiNet Plus, RS 485

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 301i SF 102

Stationary bar code reader

Series: BCL 300i

Interface: MultiNet Plus, RS 485

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 301i SF 102 D

Stationary bar code reader

Series: BCL 300i

Interface: MultiNet Plus, RS 485

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 301i SF 102 D H

Stationary bar code reader

Series: BCL 300i

Interface: MultiNet Plus, RS 485

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 301i SF 100

Stationary bar code

Series: BCL 300i

Interface: MultiNet Plus, RS 485

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 301i SF 100 D

Stationary bar code reader

Series: BCL 300i

Interface: MultiNet Plus, RS 485

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 301i SF 100 D H

Stationary bar code reader

Series: BCL 300i

Interface: MultiNet Plus, RS 485

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 301i R1 N 102

Stationary bar code reader

Series: BCL 300i

Interface: MultiNet Plus, RS 485

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 301i R1 N 102 D

Stationary bar code

Series: BCL 300i

Interface: MultiNet Plus, RS 485

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 301i R1 N 100

Stationary bar code reader

Series: BCL 300i

Interface: MultiNet Plus, RS 485

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 301i R1 N 100 D

Stationary bar code reader

Series: BCL 300i

Interface: MultiNet Plus, RS 485

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 301i R1 M 102

Stationary bar code reader

Series: BCL 300i

Interface: MultiNet Plus, RS 485

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 301i R1 M 102 D

Stationary bar code reader

Series: BCL 300i

Interface: MultiNet Plus, RS 485

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 301i R1 M 100

Stationary bar code reader

Series: BCL 300i

Interface: MultiNet Plus, RS 485

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 301i R1 M 100 D

Stationary bar code reader

Series: BCL 300i

Interface: MultiNet Plus, RS 485

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 301i R1 F 102

Stationary bar code reader

Series: BCL 300i

Interface: MultiNet Plus, RS 485

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 301i R1 F 102 D

Stationary bar code

Series: BCL 300i

Interface: MultiNet Plus, RS 485

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 301i R1 F 100

Stationary bar code reader

Series: BCL 300i

Interface: MultiNet Plus, RS 485

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 301i R1 F 100 D

Stationary bar code reader

Series: BCL 300i

Interface: MultiNet Plus, RS 485

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 301i OM 100 D H

Stationary bar code reader

Series: BCL 300i

Interface: MultiNet Plus, RS 485

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 301i OM 100 D

Stationary bar code

Series: BCL 300i

Interface: MultiNet Plus, RS 485

Functions: AutoControl, Alignment mode, AutoConfig, AutoReflA...



BCL 301i OM 100

Stationary bar code reader

Series: BCL 300i

Interface: MultiNet Plus, RS 485

Functions: AutoControl, Alignment mode, AutoConfig, AutoReflA...



BCL 301i OL 100 D H

Stationary bar code reader

Series: BCL 300i

Interface: MultiNet Plus, RS 485

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 301i OL 100 D

Stationary bar code reader

Series: BCL 300i

Interface: MultiNet Plus, RS 485

Functions: AutoControl, Alignment mode, AutoConfig, AutoReflA...



BCL 301i OL 100

Stationary bar code reader

Series: BCL 300i

Interface: MultiNet Plus, RS 485

Functions: AutoControl, Alignment mode, AutoConfig, AutoReflA...



BCL 301i OF 100 D H

Stationary bar code reader

Series: BCL 300i

Interface: MultiNet Plus, RS 485

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 301i OF 100 D

Stationary bar code reader

Series: BCL 300i

Interface: MultiNet Plus, RS 485

Functions: AutoControl, Alignment mode, AutoConfig, AutoReflA...



BCL 301i OF 100

Stationary bar code reader

Series: BCL 300i

Interface: MultiNet Plus, RS 485

Functions: AutoControl, Alignment mode, AutoConfig, AutoReflA...



BCL 300i SN 102

Stationary bar code

Series: BCL 300i

Interface: RS 422, RS 232

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 300i SN 102 D

Stationary bar code reader

Series: BCL 300i

Interface: RS 422, RS 232

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 300i SN 102 D H

Stationary bar code reader

Series: BCL 300i

Interface: RS 422, RS 232

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 300i SN 100

Stationary bar code reader

Series: BCL 300i

Interface: RS 422, RS 232

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 300i SN 100 D

Stationary bar code

Series: BCL 300i

Interface: RS 422, RS 232

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 300i SN 100 D H

Stationary bar code reader

Series: BCL 300i

Interface: RS 422, RS 232

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 300i SM 102

Stationary bar code reader

Series: BCL 300i

Interface: RS 422, RS 232

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 300i SM 102 D

Stationary bar code reader

Series: BCL 300i

Interface: RS 422, RS 232

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 300i SM 102 D H

Stationary bar code reader

Series: BCL 300i

Interface: RS 422, RS 232

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 300i SM 100

Stationary bar code reader

Series: BCL 300i

Interface: RS 422, RS 232

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 300i SM 100 D

Stationary bar code reader

Series: BCL 300i

Interface: RS 422, RS 232

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 300i SM 100 D H

Stationary bar code reader

Series: BCL 300i

Interface: RS 422, RS 232

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 300i SL 102

Stationary bar code

Series: BCL 300i

Interface: RS 422, RS 232

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 300i SL 102 D

Stationary bar code reader

Series: BCL 300i

Interface: RS 422, RS 232

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 300i SL 102 D H

Stationary bar code reader

Series: BCL 300i

Interface: RS 422, RS 232

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 300i SL 100

Stationary bar code reader

Series: BCL 300i

Interface: RS 422, RS 232

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 300i SL 100 D

Stationary bar code

Series: BCL 300i

Interface: RS 422, RS 232

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 300i SL 100 D H

Stationary bar code reader

Series: BCL 300i

Interface: RS 422, RS 232

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 300i SF 102

Stationary bar code reader

Series: BCL 300i

Interface: RS 422, RS 232

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 300i SF 102 D

Stationary bar code reader

Series: BCL 300i

Interface: RS 422, RS 232

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 300i SF 102 D H

Stationary bar code reader

Series: BCL 300i

Interface: RS 422, RS 232

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 300i SF 100

Stationary bar code reader

Series: BCL 300i

Interface: RS 422, RS 232

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 300i SF 100 D

Stationary bar code reader

Series: BCL 300i

Interface: RS 422, RS 232

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 300i SF 100 D H

Stationary bar code reader

Series: BCL 300i

Interface: RS 422, RS 232

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 300i R1 N 102

Stationary bar code

Series: BCL 300i

Interface: RS 422, RS 232

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 300i R1 N 102 D

Stationary bar code reader

Series: BCL 300i

Interface: RS 422, RS 232

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 300i R1 N 100

Stationary bar code reader

Series: BCL 300i

Interface: RS 422, RS 232

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 300i R1 N 100 D

Stationary bar code reader

Series: BCL 300i

Interface: RS 422, RS 232

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 300i R1 M 102

Stationary bar code

Series: BCL 300i

Interface: RS 422, RS 232

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 300i R1 M 102 D

Stationary bar code reader

Series: BCL 300i

Interface: RS 422, RS 232

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 300i R1 M 100

Stationary bar code reader

Series: BCL 300i

Interface: RS 422, RS 232

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 300i R1 M 100 D

Stationary bar code reader

Series: BCL 300i

Interface: RS 422, RS 232

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 300i R1 F 102

Stationary bar code reader

Series: BCL 300i

Interface: RS 422, RS 232

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 300i R1 F 102 D

Stationary bar code reader

Series: BCL 300i

Interface: RS 422, RS 232

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 300i R1 F 100

Stationary bar code reader

Series: BCL 300i

Interface: RS 422, RS 232

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 300i R1 F 100 D

Stationary bar code reader

Series: BCL 300i

Interface: RS 422, RS 232

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 300i OM 100 D H

Stationary bar code

Series: BCL 300i

Interface: RS 422, RS 232

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 300i OM 100 D

Stationary bar code reader

Series: BCL 300i

Interface: RS 422, RS 232

Functions: AutoControl, Alignment mode, AutoConfig, AutoReflA...



BCL 300i OM 100

Stationary bar code reader

Series: BCL 300i

Interface: RS 422, RS 232

Functions: AutoControl, Alignment mode, AutoConfig, AutoReflA...



BCL 300i OL 100 D H

Stationary bar code reader

Series: BCL 300i

Interface: RS 422, RS 232

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 300i OL 100 D

Stationary bar code

Series: BCL 300i

Interface: RS 422, RS 232

Functions: AutoControl, Alignment mode, AutoConfig, AutoReflA...



BCL 300i OL 100

Stationary bar code reader

Series: BCL 300i

Interface: RS 422, RS 232

Functions: AutoControl, Alignment mode, AutoConfig, AutoReflA...



BCL 300i OF 100 D H

Stationary bar code reader

Series: BCL 300i

Interface: RS 422, RS 232

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...



BCL 300i OF 100 D

Stationary bar code reader

Series: BCL 300i

Interface: RS 422, RS 232

Functions: AutoControl, Alignment mode, AutoConfig, AutoReflA...



BCL 300i OF 100

Stationary bar code reader

Series: BCL 300i

Interface: RS 422, RS 232

Functions: AutoControl, Alignment mode, AutoConfig, AutoReflA...



BCL 308i SF 102 D

Stationary bar code reader

Series: BCL 300i

Interface: Ethernet

Functions: AutoConfig, Alignment mode, AutoControl, AutoReflA...

По вопросам продаж и поддержки обращайтесь:

Алматы (727)345-47-04
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Саранск (8342)22-96-24
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +(727)345-47-04

Беларусь +(375)257-127-884

Узбекистан +998(71)205-18-59

Киргизия +996(312)96-26-47

эл.почта: ezu@nt-rt.ru || сайт: <https://leuze.nt-rt.ru/>